## Installation Manual

- 1. Drill 3 ¼ inch holes according to the thermostat template.
- 2. Insert plastic wall anchors and mount the thermostat to the wall using the included 6/32 screws .
- 3. Insert batteries if 24 volts is not available.
- 4. Remove the AC power to the air conditioner.
- 5. Connect the colored wires of the control card to the air conditioner unit carefully following the color labels on the air conditioner
- 6. Power up the air conditioner.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT